

Antimicrobial Floor Finish











Altra Antimicrobial Floor Finish utilizes Microban® antimicrobial technology, providing 24/7 protection to help inhibit the growth of bacteria on floors. Altra Antimicrobial Floor Finish is formulated with proprietary Renaissance Performance Polymers and offers unique attributes such as alcohol resistance, clarity, durability, and repairability. Fast-drying for healthcare environments, Altra Antimicrobial Floor Finish is the prescribed choice for refinishing hospital hallways and rooms efficiently.*



FLOOR CARE

Alcohol resistant







Directions for use

Floor Preparation:

- 1. Strip floor using Altra Low Odor Floor Stripper.
- 2. After picking up solution, rinse floor until no residue remains.
- 3. Allow floor to dry before applying Altra Antimicrobial Floor Finish.

Application:

- 1. Apply finish in even coats 750 sq. ft./48 oz.
- 2. Allow each coat to dry, usually 20 to 30 minutes.
- 3. Apply multiple coats until desired gloss is achieved.

Using Altra Lite Applicator:

- 1. Use an Altra Lite applicator with a clean and rinsed microfiber finish mop.
- 2. Saturate microfiber finish mop with water and ring out prior to applying finish.

Using Standard String Mop:

- 1. Use a clean mop and bucket with a new trash liner.
- 2. Saturate mop, press firmly into wringer to remove excess finish. Do not wring mop.

Maintenance:

- 1. Dust mop floor.
- 2. Damp mop floor as needed, using Altra Multi-Purpose HP Cleaner.

Available Packaging: 8 × 48 oz. bottle 2 Gallon Mini Pac

Altra Antimicrobial Floor Finish Technical Specifications	
рН	8.4 ± 0.2
Leveling	Excellent
Odor	Low
Freeze/Thaw Stability	Passes 3 cycles
Removability	Excellent
Dry Time	20-25 minutes
Alcohol Resistance	Good-Excellent
Black Mark Resistance	Excellent
Film Color	Water-Clear
Scrubability	Excellent
Weight/Gallon	8.53 lbs.
Slip Resistance	UL Classified





