

EX7000 & Altra Tablets Post-Acute Usage Guide

EX7000 - Electrostatic Backpack Sprayer

1. EMist recommends the use of disinfecting products on EPA's Disinfection List N that are approved for electrostatic application.

(2.) Begin at the farthest point from the doorway, work back toward the doorway so you can step out when application is complete.

- 3. Aim applicator wand 24"-36" (optimal distance) from the surface target area, begin with a smooth figure "S" movement aiming below at, and above the surface target area while walking at an average pace (continuously moving).
- **4.** Make sure you are working in a methodical "S" pattern and let your passes overlap when moving to the next surface target area.
- **(5.)** Allow treated area to sit for contact time as recommended by the chemical manu facturer's label before re-entry into the area.

The system is designed to minimize maintenance and cleaning. Clear the system at least once a day by spraying clean water through the system for at least 1-2 minutes.

> Some chemicals are harsher or more volatile than others. Because corrosion caused by chemicals is not covered under Manufacturer's limited warranty, it is imperative that you properly flush the system as directed herein. Note that the use of some chemicals may require more frequent flushing of the system based on the chemicals corrosive nature. Signs of failing to properly flush the system include clogged nozzle, hardened or calcified hoses or lines, deterioration of the plastics such as the manifold, and/or clogged filters.

> > (eep batteries charged.

nspect cord for cuts, tears, or damage.

Inspect applicator for debris or damage.

Altra Disinfecting Tablets

Altra Effervescent Tablet Solution Instructions for Use. Follow specific directions for use and dilution chart when preparing solution. Prepare a fresh solution Daily. Prepare solution strength as required, refer to the dilution chart for correct dose, usage, and contact times for the prepared solution. (Refer to chart below)

Solution Preparation Instructions.

- · Don gloves to handle tablets safely and according to chemical manufacturer's instructions.
- Fill mixing container with tap water to the desired level line.
- Simply, drop effervescent tablet(s) into mixing container, let dissolve for

4 minutes or until tablet(s) are not visible.

| тіс | MALTRA" |
|--|---|
| r chemical-reso- tion. Wesh | Disinfecting Tablets |
| drawing, chewing would clothing | Kills Clostridioides difficile spores in 4 minutes! Kills biofilm bacteria* Effective spins SARD-CaV-2 the cause of COVID 19 on hark, emproves indicase |
| ny into water. 85 or any other hold, liberation of Autoid any contact | Sustainable - Broad spectrum disinfectant - Disinfects - Cleans - Kits 99 PK of bacteria - Simple to use - Neutral pH |
| not ane this (Intergenic or). Such use may nemperatures | ACTIVE INGREDIENT: Sodium dichtersHaltmehnene 48,21%* OTHER INGREDIENTS: 51.79% TOTAL: "Reserved to 31.5% active cleaner by later aregin: Net to dichter shert for Andräge Ottome concentration. |
| ete el bis product acility | ит сонтонта лина или на |
| | KEEP OUT OF REACH OF CHILDRED DATA OF THE AND |
| W: T016 XP: 12-223 | animal conservative and mark the databases that do adult as shown and the same a |

| Tablets per 1 Gallon of Water | Usage | Contact Time |
|----------------------------------|---|---|
| 1 | General Disinfection | 10 minutes |
| 2 | General Disinfection | 10 minutes |
| 4 | Sporicidal Claim for C. Diff | 4 minutes |
| | and the second secon | Gallon of WaterUsage1General Disinfection2General Disinfection4Sporicidal Claim |

MasVidaHealth.com | 877.790.5994 133 Nursery Lane, Fort Worth, TX 76114

MVC - EX7000 and Altra Tablets Post-Acute Usage Guide - Poster - 063023 | QR - MVC - Home

All trademarks, service marks, and company names are the property of their respective owners. Any products or services offered by MasVida Health Care Solutions, LLC (MasVida) are subject to customer entering into a written customer agreement with MasVida. MasVida is a preferred post-acute distributor of Altra™.

EX7000

emist



